# SECTION 01782 - SPARE PARTS AND MAINTENANCE MANUALS

## PART 1 - GENERAL

### 1.1 REQUIREMENTS INCLUDED

A. Products required.

B. Storage and delivery of products.

### 1.2 RELATED REQUIREMENTS

A. Section 01610 - BASIC PRODUCT REQUIREMENTS.

B. Section 01770 - CLOSEOUT PROCEDURES.

C. Section 01830 - OPERATION AND MAINTENANCE DATA.

D. Individual Specifications Sections: Specific spare parts and materials required.

### 1.3 PRODUCTS REQUIRED

A. Provide quantities of products, spare parts, maintenance tools and maintenance materials specified in individual sections to be provided to Owner in addition to that required for completion of Work.

B. Products: Identical to those installed in the Work. Include quantities in original purchase from supplier or manufacturer to avoid variations in manufacturer.

### 1.4 STORAGE, MAINTENANCE

A. Store products with products to be installed in the Work under provisions of Section 01610.

B. After delivery of products to site, maintain spare products in same space and condition as products to be installed in the Work.

C. Maintain spare products in original containers with labels intact and legible until delivery to Owner.

### 1.5 DELIVERY

A. Coordinate with Owner THROUGH THE CONSTRUCTION MANAGER: Deliver and unload spare products to Owner at Project site and obtain receipt prior to final payment.

## PART 3 - EXECUTION (Not Applicable).

END OF SECTION